

How you do it:

1. Remove magazine and make sure gun is clear
2. Remove the slide
3. Remove top grip screws



4. Insert the Extractor



5. Insert Special Grip Screws and tighten



6. Align Grabber and Slide-stop pin hole and slide on the barrel...



...be sure to align Extractor with slot.



7. Insert slide-stop pin



8. Tighten bolt with supplied allen wrench - take care not to over tighten.

